



Poly-Tubing Wire Management Installation Instructions

Purpose: To manage wire.



- ① Manage the loose wire and connector cables to the cabinet by sliding the 1.5" split poly-tubing over the wire.
- ② Clean the area with the alcohol swab provided and let dry.
- ③ Removing the double-back tape cover and adhere to the cabinet.