



Wifi Power Supply Set Up

1. Download the “ Miboxer Smart” App and sign up new account
2. Make sure your device is connected to your home Wi-Fi network
(Only works on 2.4g Wi-Fi connection)
3. Plug in the power unit with your Wi-Fi controller
4. Press (+) at the top right of your app home screen
5. The device will show up on screen saying “devices to be added”, select that device. If it doesn’t unplug power supply for 10 seconds and then plug back in.
6. Select your 2.4g Wi-Fi connection
7. Once the device has been added your lights will blink 3 times.
8. Enjoy!!!



Wifi Power Supply Set Up

1. Download the “ Miboxer Smart” App and sign up new account
2. Make sure your device is connected to your home Wi-Fi network
(Only works on 2.4g Wi-Fi connection)
3. Plug in the power unit with your Wi-Fi controller
4. Press (+) at the top right of your app home screen
5. The device will show up on screen saying “devices to be added”, select that device. If it doesn’t unplug power supply for 10 seconds and then plug back in.
6. Select your 2.4g Wi-Fi connection
7. Once the device has been added your lights will blink 3 times.
8. Enjoy!!!



Wifi Power Supply Set Up

1. Download the “ Miboxer Smart” App and sign up new account
2. Make sure your device is connected to your home Wi-Fi network
(Only works on 2.4g Wi-Fi connection)
3. Plug in the power unit with your Wi-Fi controller
4. Press (+) at the top right of your app home screen
5. The device will show up on screen saying “devices to be added”, select that device. If it doesn’t unplug power supply for 10 seconds and then plug back in.
6. Select your 2.4g Wi-Fi connection
7. Once the device has been added your lights will blink 3 times.
8. Enjoy!!!



Wifi Power Supply Set Up

1. Download the “ Miboxer Smart” App and sign up new account
2. Make sure your device is connected to your home Wi-Fi network
(Only works on 2.4g Wi-Fi connection)
3. Plug in the power unit with your Wi-Fi controller
4. Press (+) at the top right of your app home screen
5. The device will show up on screen saying “devices to be added”, select that device. If it doesn’t unplug power supply for 10 seconds and then plug back in.
6. Select your 2.4g Wi-Fi connection
7. Once the device has been added your lights will blink 3 times.
8. Enjoy!!!

For additional product or installation assistance please call 410-287-3232

CLASS 2 OUTPUT. DRY LOCATIONS ONLY/POUR EMPLACEMENTS SECS SEULEMENT. NOT FOR USE WITH SUBMERSIBLE FIXTURES. TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT/POUR EVITER LED CHOCS ELECTRIQUES, INTRODUIRE LA LAME LA PLUS LARGE DE LA FICHE DANS LA FENTE LA PLUS LARGE. WARNING—RISK OF ELECTRIC SHOCK. INSTALL POWER UNIT 10 FEET (3.0 M) OR MORE FROM POOL, SPA, OR FOUNTAIN. ONLY USE THE EXTENSION CORD SUPPLIED WITH THE PROVIDED POWER SUPPLY. DO NOT USE AN EXTENSION CORD. 10MM ILUMA PULS 3 WATTS PER FOOT. 5MM ILUMA PULLS 1.6 WATTS PER FOOT. USE ONLY 90% OF THE POWER SUPPLIES WATTAGE, ALLOWING 10% FREE. RISK OF FIRE. IF INSTALLATION INVOLVES RUNNNG WIRING THORUGH A BUILDING

For additional product or installation assistance please call 410-287-3232.

CLASS 2 OUTPUT. DRY LOCATIONS ONLY/POUR EMPLACEMENTS SECS SEULEMENT. NOT FOR USE WITH SUBMERSIBLE FIXTURES. TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT/POUR EVITER LED CHOCS ELECTRIQUES, INTRODUIRE LA LAME LA PLUS LARGE DE LA FICHE DANS LA FENTE LA PLUS LARGE. WARNING—RISK OF ELECTRIC SHOCK. INSTALL POWER UNIT 10 FEET (3.0 M) OR MORE FROM POOL, SPA, OR FOUNTAIN. ONLY USE THE EXTENSION CORD SUPPLIED WITH THE PROVIDED POWER SUPPLY. DO NOT USE AN EXTENSION CORD. 10MM ILUMA PULS 3 WATTS PER FOOT. 5MM ILUMA PULLS 1.6 WATTS PER FOOT. USE ONLY 90% OF THE SUPPLIES WATTAGE, ALLOWING 10% FREE. RISK OF FIRE. IF INSTALLATION INVOLVES RUNNNG WIRING THORUGH A BUILDING STRUCTURE, SPECIAL WIRING METHODS ARE NEEDED. CONSULT A QUALIFIED

For additional product or installation assistance please call 410-287-3232.

CLASS 2 OUTPUT. DRY LOCATIONS ONLY/POUR EMPLACEMENTS SECS SEULEMENT. NOT FOR USE WITH SUBMERSIBLE FIXTURES. TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT/POUR EVITER LED CHOCS ELECTRIQUES, INTRODUIRE LA LAME LA PLUS LARGE DE LA FICHE DANS LA FENTE LA PLUS LARGE. WARNING—RISK OF ELECTRIC SHOCK. INSTALL POWER UNIT 10 FEET (3.0 M) OR MORE FROM POOL, SPA, OR FOUNTAIN. ONLY USE THE EXTENSION CORD SUPPLIED WITH THE PROVIDED POWER SUPPLY. DO NOT USE AN EXTENSION CORD. 10MM ILUMA PULS 3 WATTS PER FOOT. 5MM ILUMA PULLS 1.6 WATTS PER FOOT. USE ONLY 90% OF THE POWER SUPPLIES WATTAGE, ALLOWING 10% FREE. RISK OF FIRE. IF INSTALLATION INVOLVES RUNNNG WIRING THORUGH A BUILDING

For additional product or installation assistance please call 410-287-3232.

CLASS 2 OUTPUT. DRY LOCATIONS ONLY/POUR EMPLACEMENTS SECS SEULEMENT. NOT FOR USE WITH SUBMERSIBLE FIXTURES. TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT/POUR EVITER LED CHOCS ELECTRIQUES, INTRODUIRE LA LAME LA PLUS LARGE DE LA FICHE DANS LA FENTE LA PLUS LARGE. WARNING—RISK OF ELECTRIC SHOCK. INSTALL POWER UNIT 10 FEET (3.0 M) OR MORE FROM POOL, SPA, OR FOUNTAIN. ONLY USE THE EXTENSION CORD SUPPLIED WITH THE PROVIDED POWER SUPPLY. DO NOT USE AN EXTENSION CORD. 10MM ILUMA PULS 3 WATTS PER FOOT. 5MM ILUMA PULLS 1.6 WATTS PER FOOT. USE ONLY 90% OF THE POWER SUPPLIES WATTAGE, ALLOWING 10% FREE. RISK OF FIRE. IF INSTALLATION INVOLVES RUNNNG WIRING THORUGH A BUILDING STRUCTURE, SPECIAL WIRING METHODS ARE NEEDED. CONSULT A QUALIFIED ELECTRICIAN.